

min 10mm gap between insulation and breather or counter battens to allow water run off

permavent breather membrane

permavent-tape (double-sided)

permavent-tray eaves guard

cavity clousure

insulation

insulation

permavent - dry vapour control layer

insulation

